

Thigh Braces Installation

Paddlers wishing a tighter fit have the option to add stage 2 system to stage 1.

1. Before starting stage 2 installation, you have to remove stage 1 (No.6) if already installed on the kayak.
2. To install stage 2 (No.3), you need a 5/32" Allen key. This Allen key and all required parts listed below are included with the installation kit.
3. You also need three stainless steel washers (No.2):
 - o One stainless steel washer between the screw and the tightening plate
 - o One stainless steel washer on each side of the tightening plate
4. There are three possible adjustments for stage 2:
 - o Without a plastic washer with the 1 1/4" screw (No.1)
 - o With a 1/4" washer (No.4) with the 1 1/4" screw (No.1)
 - o With two 1/4" washers (No.4), to reach 1/2" in height, the 1 1/2" screw (No.1).
5. Fix the screw on the tightening plate (No.5). Don't tighten the screw to the maximum.
6. Reinstall stages 1 and 2 on the kayak. Adjust the thigh brace according to your morphology and tighten the screw (No.1). Make sure the brass insert is visible when screwed in stage 1 (No.7).

