




Thigh-brace Installation (stage 1)

1. Place a mark in the inside centre, at the front of the cockpit;
2. Using a measuring tape, measure 7" diagonally; and mark;
3. Align the front of the thigh-brace rim with the mark;



4. Sit in the kayak and check the thigh-brace position;
5. Use a 3/16" bit to drill holes (two per thigh-brace);
6. Hold the thigh-brace in position against the inside of the cockpit rim and drill through the kayak using the existing thigh-brace holes as guides. Drill one hole as illustrated, install the hardware and then drill a second hole;



7. Insert the 10-24 X 5/8" screw in the hole and install the 10-24 finishing nut. Tighten the finishing nut.